



USE EXISTING EXPANSION JOINT OR SAWCUT AND PLACE COLD JOINT.



**NOTES: SECTION A-A**

**M**

2. CURB JOINT SHALL BE A TROWELED JOINT WITH A MINIMUM 1/2" RADIUS ALONG BACK OF CURB.
3. ISOLATION JOINTS SHALL BE 1/2" PREMOLDED ASPHALT IMPREGNATED MATERIAL EXTENDING FROM SUBGRADE TO FINISHED GRADE, NO WOOD PRODUCTS ALLOWED.
4. EXPANSION JOINT SPACING SHALL BE A MAXIMUM OF 12'.
5. SUB GRADE SHALL BE FIRM WITH NO SOFT SPOTS WITH A MINIMUM OF 2" OF 3/4 - 0" ROCK
6. STEEL TIES 9" LONG DRILL HOLE 3" INTO EXISTING CURB 4# BAR 24" ON CENTER.

**LEGEND:**

- ↓ CROSS SLOPE 1.5% MAX (MAX 2.0 % FINISHED SURFACE SLOPE)
- ← RUNNING SLOPE 7.5% MAX (MAX 8.3% FINISHED SURFACE SLOPE)



**RESIDENTIAL DRIVEWAY  
(CURBSIDE SIDEWALK)**

ENGINEERING  
DEPARTMENT  
1924 COUNCIL STREET  
P.O. BOX 326  
FOREST GROVE, OR 97116

DRAWING NO.  
110

SCALE  
NONE